

Storm Water Pollution Prevention Plan

Nordic Mountain Pipeline Replacement

07/12/2012

Best Management Practices (BMP)

1. Trenches will be backfilled at the end of each day.
 2. A water truck and broom will be on site and roadways will be cleaned each working day to remove fugitive dust.
 3. A vegetative barrier of 15' already exists and will be maintained to protect bodies of water.
 4. Road base or existing surface material will be put back on the surface.
 5. Any dirt that is piled on the site will be placed so that it cannot get into drainages or will be protected.
 6. If necessary, straw wattles or other barriers will be placed in the approaches to inlets or other locations where settlement is needed.
-